
MyTiCon Timber Connectors Whitepaper



Roof-to-Wall Connections (Truss Uplift)

By Max Closen Dipl.-Ing (FH), MaSc



TYPICAL ASSY INSTALLATION-TRUSS ALIGNED W/STUD WOOD you like to CONNECT?

CONTACT US

sales@my-ti-con.com

west coas

604.349.8426

East Coa

438.862.1226

Technical Support

info@mv-ti-con.com



Understanding & Specifying Engineered Structural SWG ASSY® Screws




General information

This document provides design concepts for roof-to-wall connections using Code approved SWG ASSY® VG Cyl. screws. The recommendations are based on the following conditions:

- Rafters or truss members with a minimum cross section of 2x6" (38x140 mm)
- Studs from the framing below with a minimum cross section of 2x4" (38x89 mm) of No. 2 or better grade S-P-F lumber
- Double 2"x (38 mm x) wall top plate of No. 2 or better grade S-P-F lumber
- Continuous load path to other structural members to be provided by a registered design professional

Conditions of use

- Side member of the roof-to-wall connection is a 2x" (38 mm) wall top plate of No. 2 or better grade S-P-F lumber
- Main member of the roof-to-wall connection is a rafter, truss member or stud of No. 2 or better grade S-P-F lumber
- Splices in upper or lower plate with at least 1/4" (6 mm) offset to the center of the side member. The maximal width of the gap in the splice shall not be greater than the inner thread diameter:
 0.15" (3.8 mm)



MyTiCon Timber Connectors Whitepaper





Suggested resistances for SWG ASSY® VG screws in roof-to-wall connections

The outlined resistances are based on the CSA 086-09, the issued CCMC report "CCMC 13677-R" and boundary conditions outlined in the European Technical Approval "ETA-11/0190".


Maximum suggested resistances are provided in table 1 & 2.

Suggested resistances are based on the following conditions:

- Listed factored resistances apply to mean oven dry relative density and specific gravity (SG) as outlined in respective tables
- Angle between screw axis and wood grain in the side member is α = 90°.
 Angle between screw axis and wood grain of rafter/truss member not to be smaller than α = 45°.
 In studs angle between screw axis and wood grain shall not be less than α = 15°.
- A wood moisture content of 12% ±2%
- Applied modification factors are $K_{SF} = 1$, $K_T = 1$ and either $K_D = 1.15$ for wind uplift ("short term loading") or $K_D = 1.00$ for lateral loads ("standard term loading")
- For withdrawal resistance the threaded length only less one diameter for the tip is considered.



Understanding & Specifying Engineered Structural SWG ASSY® Screws



Design and installation procedure

- Suggested factored resistances (uplift and lateral load) are outlined in table 1.
- SWG ASSY® VG Screws to be installed in the center of the stud width b_{stud} at an installation angle of $15^{\circ} \le \delta \le 20^{\circ}$
- Spacing end and edge distance requirements as per table 4 shall be followed.
- SWG ASSY® VG Screws are to be driven top flush to the surface of the double top plate. Do not over-drive screw head in side member.
- Splices in upper or lower plate shall be set off to the SWG ASSY® VG Screw axis of min. 1/4" (6 mm)

Table 1: factored uplift and shear resistances for SWG ASSY® VG screws in double top plate-to-stud connections

Factored shear and uplift resistance ¹ per SWG ASSY® VG Cyl. Screw ² in connections of top plates to studs								
Diameter	Minor-Ø	Screw length	Uplift resist	ance P _{r,u} ^{1,3}	Shear resistance P _{r,s1} 1,4		Shear resistance P _{r,s2} ^{1,4}	
in (mm)	in (mm)	in (mm)	kN	lbs	kN	lbs	kN	lbs
1/4 (6)	0.15 (3.8)	7-7/8 (200)	3.11	701	0.55	123	0.46	104

Notes: ¹ For load combinations of withdrawal and shear the following condition shall apply:

: uplift load

P_{r,u}: factored uplift resistance ³ $(T_{fu}/P_{r,u})^2 + (V_{fs1}/P_{r,s1})^2 + (V_{fs2}/P_{r,s2})^2 \le 1$

 $V_{fs1(2)}$: shear load as per picture above

P_{r,s1(2)}: factored shear resistance ⁴


² Installation angle δ limited to: 15° ≤ δ ≤ 20°. Install screw in the center of the stud width b_{stud}

 $^{^3}$ K_{SF} = 1.0, K_T = 1.0, K_D = 1.15 and SWG ASSY® VG Cyl. Screws assembled as per <u>design and installation procedure</u>

⁴ K_{SF} = 1.0, K_T = 1.0, K_D = 1.00 and SWG ASSY® VG Cyl. Screws assembled as per <u>design and installation procedure</u>

Understanding & Specifying Engineered Structural SWG ASSY® Screws

Double top plate-to-rafter/truss member connection



Design and installation procedure

- Suggested factored resistances (uplift load) are outlined in table 2.
- SWG ASSY® VG Screws to be installed in the center of rafter or truss member width b_{raft}
- When Truss/rafters above stud SWG ASSY® VG Screws to be installed at an installation angle δ : 25° $\leq \delta \leq$ 45°.
- When Truss/rafters are offset to stud SWG ASSY® VG Screws to be installed perpendicular and top flush to the surface of the lower plate with a minimum edge distance of 3/4" (20 mm).
- Do not over-drive screw head in side member.
- Spacing, end and edge distance requirements as per table 4 shall be followed.

Table 2: factored uplift resistance for SWG ASSY® VG Screws in double top plate-to-rafter or truss member connections

Factored resistance ¹ per SWG ASSY® VG Cyl. Screw in connections of rafter/truss members to top plates							
Rafter/ truss	Diameter	Minor-Ø	Screw length	Uplift resistance P _{r,u} 1,3		Shear resistance P _{r,s} ^{1,4}	
member position	in (mm)	in (mm)	in (mm)	kN	lbs	kN	lbs
CASE 1 ²	1/4 (6)	0.15 (3.8)	7-7/8 (200)	2.75	617	1.43	321
CASE 2 ⁵	1/4 (6)	0.15 (3.8)	7-7/8 (200)	3.65	817	0.55	123

Notes: ¹ For load combinations of withdrawal and shear the following condition shall apply:

Tfu: uplift load

P_{r,u}: factored uplift resistance³

 $(T_{fu}/P_{r.u})^2 + (V_{fs||}/P_{r.s})^2 + (V_{fs||}/P_{r.s})^2 \le 1$ $V_{fs||}$: shear force parallel to top plate grain direction

 $V_{fs\perp}$: shear force perpendicular to top plate grain direction

P_{r,s}: factored shear resistance ⁴

² Installation angle δ limited to: 25° ≤ δ ≤ 45°. Install screw in center of rafter/truss width b_{raft}

 $^{^3}$ K_{SF} = 1.0, K_T = $\stackrel{-}{1.0}$, K_D = 1.15 and SWG ASSY® VG Screws assembled as per <u>design and installation procedure</u>.

⁴ K_{SF} = 1.0, K_T = 1.0, K_D = 1.00 and SWG ASSY® VG Screws assembled as per <u>design and installation procedure</u>.

⁵ Screw loaded in shear





SWG ASSY® VG CYL. specifications






Table 3: SWG ASSY® VG CYL. specifications

Major Ø	Length	Thread Length	Lt	Head Ø	Minor Ø	Bit		
mm								
	70	63	6	8	3.8	AW 30		
	80	73						
6	100	93						
	120	113						
	140	133						
	160	153						
	180	173						
	200	193						

Note: values listed in the table above are average measurements between upper and lower tolerance boundary

Minimum spacing, end and edge distances for SWG ASSY® VG screws

Table 4: minimum spacing requirements for SWG ASSY® VG screws

Screws loaded axially						
Min. timber thickness = 4D	S _P Spacing* parallel	S _Q Spacing* perpendicular to	a _L end distance*	e _L edge distance*		
SWG ASSY® VG	5D (7.5 in D-Fir)	2.5D	5D (7.5D in D-Fir)	3D		

Note: * Spacing and distance measured from the center of gravity of the threaded part in each member D = Major Ø (outer thread diameter)



Find more resources for our modern timber connection systems, including technical design data, installation guides, CAD files, videos, research data and more white papers on our website

www.my-ti-con.com

Or

Contact us

sales@my-ti-con.com

West Coast

604.349.8426

East Coast

438.862.1226

Technical Support 604.347.7049

info@my-ti-con.com